

**Download and Install Guide for the Zebra® LP2924 Tag Printer**  
**Operating System: Microsoft® Windows® 98**  
**QuickBooks Point of Sale Version 4**

***Download and install the printer drivers:***

1. Download the file [Zebra LP2824 Win 98](#) to your desktop.
2. Once downloaded, double-click the file on your desktop. The driver files will be automatically extracted to the following location: **C:\Drivers\Zebra LP2824 Tag Printer**. Click **Unzip** to create the directory.
3. Click **OK** on the WinZip® Self-Extractor message.
4. Ensure your printer is turned on and has tags or labels loaded.
5. Plug the printer's USB cable into an available USB port on your computer.
6. The Window's **Found New Hardware Wizard** will open.
  - a. Click **Next** to start the Wizard.
  - b. Select **Search for the best driver for my device (Recommend)** and click **Next**.
  - c. Select **Specify a location** and click **Browse**.
  - d. In the resulting window, browse to **C:\Drivers\Zebra LP 2824 Tag Printer** and then click **OK**.
  - e. Click **Next** and **Next** to install the driver.
  - f. When the software installation completes, click **Finish**.

***To configure Point of Sale to work with the Zebra Tag Printer:***

1. Start Point of Sale.
2. From the **Edit** menu, choose **Preferences** and then select **Workstation**.
3. Click **Print Options** in the preferences list.
4. Make the following selections:
  - a. Select the Zebra Tag Printer for each document you want to print with this printer.
  - b. Select an appropriate label template for each of the document types.
  - c. Click **Save**.

***Your printer is now ready to use with Point of Sale!***